

# Draining Plug for PIG® BUILD-A-BERM® Barrier

## Installation Instructions

1. Determine where you want to install your Draining Plug section.

**NOTE:** We recommend choosing the lowest point of your containment area to facilitate pump-free drainage of rain, snowmelt and other innocuous fluids.

2. Using a utility knife, cut and remove a 5" section of your installed 2"H BUILD-A-BERM® Barrier. (For new installations, simply leave a 5" gap between two sections of 2"H BUILD-A-BERM® Barrier.)



3. Scrape away old caulking with a putty knife.



4. Make sure the foam inserts of your Draining Plug section are pressed firmly against the PVC tubing in the middle.



5. Test fit the Draining Plug section in the 5" gap of your Barrier. The vinyl flaps of your Draining Plug section should overlap the BUILD-A-BERM® Barrier sections on both sides.



6. Lift out the Draining Plug section and apply silicone caulking (sold separately at newpig.com) to the ground where the Draining Plug section will be installed.



7. Apply industrial-strength vinyl cement (sold separately at newpig.com) to the overlapping flaps of your Draining Plug section.



8. Install the Draining Plug section into the 5" gap with the nylon cap on the outside of the containment area. Firmly press down to ensure a reliable seal.



**CAUTION:** Do not drive or roll over the Draining Plug section. The weight of vehicles or handtrucks can damage the PVC tubing.

**CAUTION:** This product should only be used to drain innocuous fluids, such as rain or snowmelt. Hazardous or contaminated liquids should be collected and disposed of according to federal, state and local regulations.

Still have questions? In North America contact us:



New Pig

By Phone:  
**1-800-HOT-HOGS®** (468-4647)

Online:  
**newpig.com**

E-mail:  
**hothogs@newpig.com**

One Pork Avenue • Tipton, PA 16684-0304

VH-173